



Samsung Sway Battery Replacement

How to access and replace the battery.

Written By: Chris Rush



Step 1 — Battery



- Turn the Samsung Sway over to access the rear cover.

Step 2



- Using your thumb(s) slide the cover up, and then place the cover to the side.

Step 3



- Grip the corner of the battery on either the left or right side with your fingers and lift it up to remove it.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-10-05 06:22:44 AM.